

Technical requirements specification: Activation code provisioning

Author:	Version:	Date:
Auerswald GmbH & Co. KG	1.0	21.04.17

Version tracking

Version	Date	Change	Author
1.0	21.04.2017	First version	AZE

Table of contents

Introduction.....	1
Provisioning file.....	1

1 Introduction

Additional functions like IP camera, answering machine or synchronisation can be activated via activation codes.

It is possible to provision activation codes for this function. Subsequently, the corresponding functions will be activated automatically.

2 Provisioning file

2.1 Tags

The activation must be initiated via **<activation>** tag to name the functions to be activated including the corresponding activation codes.

For this, the following tags are available:

<voicemail>

<ipcam>

<synchronisation>

2.2 Example section for the provisioning file

The following could be an example for the activation section of all three functions in a provisioning file:

```
<auerSettings ...>
  <activation>
    <voicemail>
      1234-1234-1234-1234-1234-1234
    </voicemail>
    <ipcam>
      4321-4321-4321-4321-4321-4321
    </ipcam>
    <synchronisation>
      0123-4567-8901-2345-6789-0123
    </synchronisation>
  </activation>
</auerSettings>
```