


## Instructions

The Standard.xml we are delivering in the new firmware 6.6 does not change the display or webserver language of the IP system telephone. For users who do not want to use the default language English we have prepared XML files for adapting the language. In this ZIP file you will find three XML files. They all offer the normal basic provisioning plus the language change.

Standard\_DE.xml      for change-over to German  
Standard\_GB.xml      for change-over to English  
Standard\_PL.xml      for change-over to Polish

What has to be done:

- Import the file(s) into the PBX (arrow no. 1)
- Define it/them as template (arrow no. 2)
- Assign it/them to the matching IP system telephones (arrow no. 3)



## Anleitung

Die Standard.xml, die wir mit der neuen Firmware 6.6 liefern, ändert nicht die Sprache des Telefondisplays oder des Webserver. Für Anwender, die nicht die Standardsprache Englisch nutzen wollen, haben wir XML-Dateien vorbereitet, welche die Sprache anpassen. In diesem ZIP-Archiv finden Sie drei XML-Dateien. Diese beinhalten die normale Basisprovisionierung plus die Sprachänderung.

Standard\_DE.xml      für Wechsel nach Deutsch  
Standard\_GB.xml      für Wechsel nach Englisch  
Standard\_PL.xml      für Wechsel nach Polnisch

Dies ist zu tun:

- Importieren der Datei(en) in die Telefonanlage (Pfeil Nr. 1)
- Definieren als Template (Pfeil Nr. 2)
- Den entsprechenden IP-Systemtelefonen zuordnen (Pfeil Nr. 3)